FIAT (EU) SEICENTO 187 SEICENTO 1100

(1998-2005)



ENGINE 176B2000, 187A1000 Capacity: 3,5 liter, Filter capacity: 0,4 liter				
USE		CLIMATE		
Normal		Moderate		
PRODUCT RECOMMENDATION 1				
Emperol 10W-40				
Check every 500 km, change every 15000	km/ 12 months			
USE		CLIMATE		
Normal		Arctic		
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2			
Duranza LSP 5W-30	Asyntho 5W-30			
Check every 500 km, change every 15000	km/ 12 months			

TRANSAXLE MANUAL 5/1 Capacity: 2,4 liter			
USE		CLIMATE	
Normal		Moderate	
PRODUCT RECOMMENDATION 1			
SP Gear 5015			
Check every 75000 km	<u> </u>		

HYDRAULIC BRAKE SYSTEM Capacity: 0,4 liter				
USE		CLIMATE		
Normal		Moderate		
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2			
Drauliquid-LV Super DOT 4	Drauliquid-S DOT 4			
Check every 500 km, change every 60	000 km/ 24 months			

GREASE POINTS/NIPPLES DRIVE SHAFT JOINTS			
USE	CLIMATE		
Normal	Moderate		
PRODUCT RECOMMENDATION 1			
MoS2 Grease EP 2			
MoS2 Grease EP 2			

FIAT (EU) SEICENTO 187 SEICENTO 1100 (1998-2005)



COOLING SYSTEM Capacity: 4 liter	
USE	CLIMATE
Normal	Moderate
PRODUCT RECOMMENDATION 1	
Coolant -38 Organic NF	

The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products.

Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or

advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the

Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is

information contained herein is subject to changes without notification.

Check every 15000 km