TOYOTA (FAW) RAV4 RAV4 2.0 (2013 AND AFTER)



ENGINE 6ZR Capacity: 4,2 liter		
JSE		CLIMATE
Normal		Mediterranean
PRODUCT RECOMMENDATION 1		
Bi-Turbo 20W-50		
Change every 5000 km/ 6 months		
USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Presteza MSP 0W-20	Duranza ECO 5W-20	Presteza MSP 5W-30
Change every 5000 km/ 6 months		
USE		CLIMATE
Severe		Mediterranean
PRODUCT RECOMMENDATION 1		
Bi-Turbo 20W-50		
Change every 2500 km/ 3 months		
USE		CLIMATE
Severe		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Presteza MSP 0W-20	Duranza ECO 5W-20	Presteza MSP 5W-30
Change every 2500 km/ 3 months		
Change every 2500 km/ 3 months		
TRANSAXLE CVT 1/1		
TRANSAXLE CVT 1/1 Capacity: 8,9 liter		
TRANSAXLE CVT 1/1 Capacity: 8,9 liter use		CLIMATE Moderate
TRANSAXLE CVT 1/1 Capacity: 8,9 liter use Normal		climate Moderate
TRANSAXLE CVT 1/1 Capacity: 8,9 liter use Normal PRODUCT RECOMMENDATION 1		
TRANSAXLE CVT 1/1 Capacity: 8,9 liter USE Normal PRODUCT RECOMMENDATION 1 SP Matic 4016		
TRANSAXLE CVT 1/1 Capacity: 8,9 liter use Normal PRODUCT RECOMMENDATION 1 SP Matic 4016 Check every 40000 km/24 months		Moderate
TRANSAXLE CVT 1/1 Capacity: 8,9 liter USE Normal PRODUCT RECOMMENDATION 1 SP Matic 4016 Check every 40000 km/24 months USE		Moderate
TRANSAXLE CVT 1/1 Capacity: 8,9 liter USE Normal PRODUCT RECOMMENDATION 1 SP Matic 4016 Check every 40000 km/24 months USE Severe		Moderate
Change every 2500 km/ 3 months TRANSAXLE CVT 1/1 Capacity: 8,9 liter use Normal PRODUCT RECOMMENDATION 1 SP Matic 4016 Check every 40000 km/ 24 months use Severe PRODUCT RECOMMENDATION 1 SP Matic 4016		Moderate

TOYOTA (FAW) RAV4 RAV4 2.0 (2013 AND AFTER)



TRANSMISSION MANUAL 6/1 Capacity: 2,4 liter				
USE		CLIMATE		
Normal		Moderate		
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2			
SP Gear 1081	SP Gear 5015			
Check every 40000 km/ 48 months				
USE		CLIMATE		
Severe		Moderate		
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2			
SP Gear 1081	SP Gear 5015			
Change every 40000 km/ 48 months				

ATE
erate
_

COOLING SYSTEM Capacity: 6,6 liter		
USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1		
Coolant SP 14+		
Check every 40000 km, change every 80000 km		

USE		CLIMATE	
Initial service		Moderate	
PRODUCT RECOMMENDATION 1			
Coolant SP 14+			

Check every 40000 km, change every 160000 km

The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.