

BOBCAT TELESCOPIC HANDLERS T35120L

(2004 AND AFTER)



ENGINE Perkins 1104-44T
Capacity: 8,5 liter

USE	CLIMATE
Normal	Tropical

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Multifleet SHPD 20W-50	Multifleet SCD 40	

Check every 10 hours, change every 500 hours

USE	CLIMATE
Normal	Mediterranean

PRODUCT RECOMMENDATION 1		
Multifleet SCD 30		

Check every 10 hours, change every 500 hours

USE	CLIMATE
Normal	Moderate

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Kroontrak MTH 10W-30	Synfleet SHPD 10W-40	Dieselfleet CD+ 15W-40

Check every 10 hours, change every 500 hours

USE	CLIMATE
Normal	Cold

PRODUCT RECOMMENDATION 1		
Multifleet SCD 10W		

Check every 10 hours, change every 500 hours

DIFFERENTIAL FRONT Dana
Capacity: 6,6 liter

USE	CLIMATE
Normal	Mediterranean

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Gearlube GL-5 80W-90	Unigear HS GL-3/GL-5 80W-90	

Check every 1 months/ 200 hours, change every 800 hours/ 12 months

DIFFERENTIAL REAR Dana
Capacity: 6,6 liter

USE	CLIMATE
Normal	Mediterranean

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Gearlube GL-5 80W-90	Unigear HS GL-3/GL-5 80W-90	

Check every 1 months/ 200 hours, change every 800 hours/ 12 months

BOBCAT TELESCOPIC HANDLERS T35120L

(2004 AND AFTER)



HUB REDUCTIONS FRONT

Capacity: 0,8 liter

USE		CLIMATE
Normal		Mediterranean
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Gearlube GL-5 80W-90	Unigear HS GL-3/GL-5 80W-90	

Check every 200 hours, change every 1000 hours/ 12 months

HUB REDUCTIONS REAR

Capacity: 0,8 liter

USE		CLIMATE
Normal		Mediterranean
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Gearlube GL-5 80W-90	Unigear HS GL-3/GL-5 80W-90	

Check every 200 hours, change every 1000 hours/ 12 months

TRANSFERBOX

Capacity: 0,8 liter

USE		CLIMATE
Normal		Mediterranean
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Gearlube GL-5 80W-90	Unigear HS GL-3/GL-5 80W-90	

Check every 1 months/ 200 hours, change every 800 hours/ 12 months

HYDRAULIC SYSTEM

Capacity: 77 liter (Hydraulic tank), Capacity: 125 liter (Total)

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Perlus Biosynth 46	Perlus H 46	

Check every 10 hours, change every 1000 hours/ 12 months

HYDRAULIC BRAKE SYSTEM

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Perlus Biosynth 46	Perlus H 46	

BOBCAT TELESCOPIC HANDLERS T35120L

(2004 AND AFTER)



GREASE POINTS/NIPPLES

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Labora Grease	Q5 MP Calcep Grease EP 2	MP Lithep Grease EP 2

Change every 50 hours

COOLING SYSTEM

Capacity: 17 liter

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Coolant -38 Organic NF	Coolant -26	

Check every 50 hours

The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.