

ENGINE C4.4 Acert Capacity: 16 liter		
USE		CLIMATE
Preferred		Mediterranean
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Agridiesel MSP 15W-40	Dieselfleet MSP 15W-40	

Check every 10 hours, change every 3 months/ 500 hours

USE		CLIMATE
Preferred		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Dieselfleet LSP Ultra 10W-30	Dieselfleet MSP 10W-30	

Check every 10 hours, change every 3 months/ 500 hours

USE		CLIMATE
Alternative (acceptable)		Mediterranean
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
Agrisynth MSP 10W-40	Dieselfleet MSP 15W-40	

Check every 10 hours, change every 3 months/ 500 hours

USE		CLIMATE
Alternative (acceptable)		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Agrisynth LSP Ultra FE 5W-30	Agridiesel MSP 15W-40	Dieselfleet LSP Ultra 10W-30

Check every 10 hours, change every 3 months/ 500 hours

HYDRAULIC SYSTEM Capacity: 190 liter (Change capacity)	
USE	CLIMATE
Normal	Mediterranean
PRODUCT RECOMMENDATION 1	
Gear Oil Alcat 30	

Check every 10 hours, change every 18 months/ 3000 hours

01 1 101	10 11 / 0000 1	
Agridiesel CRD+ 15W-40	Agrifluid HT-Plus	Kroontrak MTH 10W-30
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Normal		Moderate
USE		CLIMATE

Check every 10 hours, change every 18 months/ 3000 hours



USE	CLIMATE
Partial hammer use (50%)	Mediterranean
PRODUCT RECOMMENDATION 1	
Gear Oil Alcat 30	
	·

Check every 10 hours, change every 1000 hours

USE		CLIMATE
Partial hammer use (50%)		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Agridiesel CRD+ 15W-40	Agrifluid HT-Plus	Kroontrak MTH 10W-30

Check every 10 hours, change every 1000 hours

use Full time hammer use (100%)	climate Mediterranean
PRODUCT RECOMMENDATION 1	
Gear Oil Alcat 30	

Check every 10 hours, change every 600 hours

USE		CLIMATE
Full time hammer use (100%)		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Agridiesel CRD+ 15W-40	Agrifluid HT-Plus	Kroontrak MTH 10W-30

Check every 10 hours, change every 600 hours

COOLING SYSTEM Capacity: 30 liter		
USE	c	CLIMATE
Normal	N	Moderate
PRODUCT RECOMMENDATION 1		
Coolant SP 17		

Check every 10 hours, change every 36 months/ 6000 hours

SWING GEAR Capacity: 18 liter		
USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
Labora Grease	Q5 MP Calcep Grease EP 2	MP Lithep Grease EP 2
Change every 2000 hours/ 12 mon	ths	·



Normal PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Normal Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Normal Check every 1 months/ 250 hours, change every 6 months/ 1000 hours Check every 1 months/ 250 hours, change every 6 months/ 1000 hours Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 50 CLIMATE Arctic CLIMATE Arctic CLIMATE Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 50 Change every 250 hours/ 6 months CLIMATE Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Change every 250 hours/ 6 months	SWING REDUCTION UNIT Capacity: 2,4 liter			
PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Normal PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE CLIMATE Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE USE CLIMATE Moderate PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE USE CLIMATE Initial service CLIMATE Arctic PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W CLIMATE Arctic			CLIMATE	
Gear Oil Alcat 30 Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Normal PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE CLIMATE Initial Service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial Service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE Initial Service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 50 CLIMATE Arctic CLIMATE Arctic CLIMATE Arctic PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50	Normal		Moderate	
Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Normal PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE USE Initial service PRODUCT RECOMMENDATION 1 PRODUCT RECOMMENDATION 1 PRODUCT RECOMMENDATION 1 PRODUCT RECOMMENDATION 2 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE USE CLIMATE Moderate CLIMATE Arctic CLIMATE Arctic PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 CLIMATE Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W	PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2		
Normal PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service CLIMATE Moderate PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE Initial service CLIMATE Arctic CLIMATE Arctic	Gear Oil Alcat 30	Gear Oil Alcat 50		
Normal PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W CLIMATE Arctic	Check every 1 months/ 250 hours, change every 6 months/ 1000 hours			
PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W CLIMATE Arctic	USE		CLIMATE	
Gear Oil Alcat 10W Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W CLIMATE Arctic	Normal		Arctic	
Check every 1 months/ 250 hours, change every 6 months/ 1000 hours USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 2 Gear Oil Alcat 50 CLIMATE Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W	PRODUCT RECOMMENDATION 1			
Initial service Moderate PRODUCT RECOMMENDATION 1 PRODUCT RECOMMENDATION 2 Gear Oil Alcat 30 Gear Oil Alcat 50 Change every 250 hours/ 6 months USE CLIMATE Initial service Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W	Gear Oil Alcat 10W			
Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 2 CLIMATE Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Moderate Moderate Moderate Moderate Moderate	Check every 1 months/ 250 hours, change every 6 months/ 1000 hours			
PRODUCT RECOMMENDATION 1 Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W PRODUCT RECOMMENDATION 1	USE		CLIMATE	
Gear Oil Alcat 30 Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Gear Oil Alcat 10W Gear Oil Alcat 50 CLIMATE Arctic	Initial service		Moderate	
Change every 250 hours/ 6 months USE Initial service PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W CLIMATE Arctic	PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2		
USE CLIMATE Initial service Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W	Gear Oil Alcat 30	Gear Oil Alcat 50		
Initial service Arctic PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W Arctic	Change every 250 hours/ 6 months			
PRODUCT RECOMMENDATION 1 Gear Oil Alcat 10W	USE		CLIMATE	
Gear Oil Alcat 10W	Initial service		Arctic	
	PRODUCT RECOMMENDATION 1			
Change every 250 hours/ 6 months	Gear Oil Alcat 10W			



TRAVEL REDUCTION UNIT Capacity: 5 liter			
USE		CLIMATE	
Normal		Moderate	
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2		
Gear Oil Alcat 30	Gear Oil Alcat 50		
Check every 1 months/ 250 hours, change every 12 months/ 2000 hours			
USE		CLIMATE	
Normal		Arctic	
PRODUCT RECOMMENDATION 1			
Gear Oil Alcat 10W			
Check every 1 months/ 250 hours, change every 12 months/ 2000 hours			
USE		CLIMATE	
Initial service		Moderate	
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2		
Gear Oil Alcat 30	Gear Oil Alcat 50		
Change every 250 hours/ 6 months			
USE		CLIMATE	
Initial service		Arctic	
PRODUCT RECOMMENDATION 1			
Gear Oil Alcat 10W			
Change every 250 hours/ 6 months			

The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.