

DYNAPAC VIBRATORROMLE MED TO TROMLER CC/CG/LA CC122/C DEUTZ F2L- 2011 (*60119200* ->)



MOTOR Deutz F2L-2011
Kapacitet: 6,5 liter

ANVEND	KLIMA
Normal	Moderat

PRODUKTANBEFALING 1	PRODUKTANBEFALING 2	PRODUKTANBEFALING 3
Agridiesel CRD+ 15W-40	Dieselfleet CD+ 15W-40	Multifleet SHPD 15W-40

Kontroller alle 10 timer, skift alle 3 måneder/ 500 timer

ANVEND	KLIMA
Første Service	Moderat

PRODUKTANBEFALING 1	PRODUKTANBEFALING 2	PRODUKTANBEFALING 3
Agridiesel CRD+ 15W-40	Dieselfleet CD+ 15W-40	Multifleet SHPD 15W-40

Skift alle 50 timer

HYDRAULISK SYSTEM
Kapacitet: 40 liter (Hydrauliktank)

ANVEND	KLIMA
Normal	Moderat

PRODUKTANBEFALING 1		
Perlus H 68		

Kontroller alle 10 timer, skift alle 2000 timer/ 12 måneder

ANVEND	KLIMA
Biologisk nedbrydelig olie	Middelhavsagtigt

PRODUKTANBEFALING 1		
Perlus Biosynth 46		

Kontroller alle 10 timer, skift alle 2000 timer/ 12 måneder

SMØREPUNKTER/NIPLER

ANVEND	KLIMA
Normal	Moderat

PRODUKTANBEFALING 1	PRODUKTANBEFALING 2	
HT Q9 High Grade Grease	Labora Grease	

DYNAPAC VIBRATOR TROMLE MED TO TROMLER CC/CG/LA CC122/C DEUTZ F2L- 2011 (*60119200* ->)



TROMLE

Kapacitet: 5 liter

ANVEND

Normal

KLIMA

Middelhavsagtigt

PRODUKTANBEFALING 1

Gearlube GL-5 85W-140

PRODUKTANBEFALING 2

Unigear LS GL-3/GL-5 85W-140

Kontroller alle 1 måneder/ 250 timer, skift alle 12 måneder/ 2000 timer

ANVEND

Normal

KLIMA

Moderat

PRODUKTANBEFALING 1

Gearlube GL-5 80W-90

PRODUKTANBEFALING 2

Unigear HS GL-3/GL-5 80W-90

Kontroller alle 1 måneder/ 250 timer, skift alle 12 måneder/ 2000 timer

The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.