

# HAMM SINGLE DRUM COMPACTORS 3412

## VIO DEUTZ TCD 2012 L04 2V (H1800628 - >H1801346)



**ENGINE** Deutz TCD 2012 L04 2V  
Capacity: 11,5 liter (Service fill)

USE	CLIMATE
Initial service	Mediterranean

PRODUCT RECOMMENDATION 1

**Multifleet SHPD 20W-50**

*Change every 50 hours*

USE	CLIMATE
Initial service	Moderate

PRODUCT RECOMMENDATION 1

**Agrisynth LSP 10W-40**

PRODUCT RECOMMENDATION 2

**Kroontrak CVT 10W-40**

PRODUCT RECOMMENDATION 3

**Agrisynth MSP 10W-40**

*Change every 50 hours*

USE	CLIMATE
Normal, fuel sulfur level <0,5 %, ambient temperature > -10°C	Mediterranean

PRODUCT RECOMMENDATION 1

**Multifleet SHPD 20W-50**

*Change every 500 hours*

USE	CLIMATE
Normal, fuel sulfur level <0,5 %, ambient temperature > -10°C	Moderate

PRODUCT RECOMMENDATION 1

**Agrisynth LSP 10W-40**

PRODUCT RECOMMENDATION 2

**Kroontrak CVT 10W-40**

PRODUCT RECOMMENDATION 3

**Agrisynth MSP 10W-40**

*Change every 500 hours*

**DIFFERENTIAL**  
Capacity: 14 liter

USE	CLIMATE
Normal	Moderate

PRODUCT RECOMMENDATION 1

**Gearlube LS 80W-90**

*Check every 250 hours, change every 1000 hours*

USE	CLIMATE
Initial service	Moderate

PRODUCT RECOMMENDATION 1

**Gearlube LS 80W-90**

*Change every 500 hours*

**HYDRAULIC SYSTEM**

Capacity: 50 liter (Hydraulic tank)

# HAMM SINGLE DRUM COMPACTORS 3412

## VIO DEUTZ TCD 2012 L04 2V (H1800628 - >H1801346)



USE		CLIMATE
Normal		Tropical
PRODUCT RECOMMENDATION 1		
<b>Perlus H 68</b>		

*Change every 2000 hours*

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
<b>Perlus Biosynth 46</b>	<b>Perlus H 46</b>	

*Change every 2000 hours*

USE		CLIMATE
Normal		Cold
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
<b>Perlus Biosynth 32</b>	<b>Perlus H 32</b>	

*Change every 2000 hours*

USE		CLIMATE
Normal		Arctic
PRODUCT RECOMMENDATION 1		
<b>Perlus H 22</b>		

*Change every 2000 hours*

USE		CLIMATE
Biodegradable oil		Moderate
PRODUCT RECOMMENDATION 1		
<b>Perlus Biosynth 46</b>		

*Change every 2000 hours*

USE		CLIMATE
Biodegradable oil		Cold
PRODUCT RECOMMENDATION 1		
<b>Perlus Biosynth 32</b>		

*Change every 2000 hours*

### GREASE POINTS/NIPPLES

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
<b>Labora Grease</b>	<b>Q5 MP Calcep Grease EP 2</b>	<b>MP Lithep Grease EP 2</b>

# HAMM SINGLE DRUM COMPACTORS 3412 VIO DEUTZ TCD 2012 L04 2V (H1800628 - >H1801346)



## COOLING SYSTEM

Capacity: 14 liter

We are unable to give a standard recommendation for this component. Please contact our service department.

## DRUM GEARBOX

Capacity: 2 liter

We are unable to give a standard recommendation for this component. Please contact our service department.

## VIBRATOR

Capacity: 0,75 liter (each side)

We are unable to give a standard recommendation for this component. Please contact our service department.

*The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.*