

# GENIE ARTICULATING BOOMS, SELF PROPELLED BI-ENERGY Z Z-34/22DC (Z3407-5427->)



## HUB REDUCTIONS

Capacity: 0,72 liter

USE	CLIMATE
Normal	Moderate

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
<b>Gearlube GL-5 80W-90</b>	<b>Unigear HS GL-3/GL-5 80W-90</b>	

*Change every 1000 hours/ 12 months*

USE	CLIMATE
Initial service	Moderate

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	
<b>Gearlube GL-5 80W-90</b>	<b>Unigear HS GL-3/GL-5 80W-90</b>	

*Change every 150 hours*

## HYDRAULIC SYSTEM

Capacity: 22,7 liter (Hydraulic system including tank), Capacity: 15,1 liter (Hydraulic tank)

USE	CLIMATE
Normal	Moderate

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
<b>Perlus H 46</b>	<b>Perlus H 32</b>	<b>Perlus AF 46</b>

*Check every 250 hours/ 3 months, change every 24 months/ 2000 hours*

## GREASE POINTS/NIPPLES

USE	CLIMATE
Normal	Moderate

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
<b>Labora Grease</b>	<b>Q5 MP Calcep Grease EP 2</b>	<b>MP Lithep Grease EP 2</b>

## GREASE POINTS/NIPPLES WHEEL BEARINGS

USE	CLIMATE
Normal	Moderate

PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
<b>Labora Grease</b>	<b>Q5 MP Calcep Grease EP 2</b>	<b>MP Lithep Grease EP 2</b>

*Change every 2000 hours/ 24 months*

# GENIE ARTICULATING BOOMS, SELF PROPELLED BI-ENERGY Z Z-34/22DC (Z3407-5427->)



## TURNTABLE ROTATION GEAR

USE		CLIMATE
Normal		Moderate
PRODUCT RECOMMENDATION 1	PRODUCT RECOMMENDATION 2	PRODUCT RECOMMENDATION 3
<b>Labora Grease</b>	<b>Q5 MP Calcep Grease EP 2</b>	<b>MP Lithep Grease EP 2</b>

*Change every 100 hours*

*The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.*