## LEXUS (USA / CAN) RX XU30 RX 400H FWD (USA) (2006-2007)



| ENGINE 3MZ-FE<br>Capacity: 5,5 liter (Dry fill), Capacity: 4,7 liter (Service fill), Filter capacity: 0,2 liter |  |          |  |
|---|--|----------|--|
| USE   |  | CLIMATE  |  |
| Normal  |  | Moderate |  |
| PRODUCT RECOMMENDATION 1  |  |          |  |
| Presteza MSP 5W-30  |  |          |  |
| Oh  |  |          |  |

Change every 5000 miles/ 6 months

| TRANSAXLE HYBRID SYSTEM P310 1/1<br>Capacity: 4,2 liter (with towing package), Capacity: 3,9 liter (without towing package) |  |          |
|---|--|----------|
| USE   |  | CLIMATE  |
| Normal  |  | Moderate |
| PRODUCT RECOMMENDATION 1  |  |          |
| SP Matic 4036   |  |          |
| Check every 30000 miles/ 36 months  |  |          |
| USE   |  | CLIMATE  |

| USE   |  | CLIMATE  |
|---|--|----------|
| Severe  |  | Moderate |
| PRODUCT RECOMMENDATION 1  |  |          |
| SP Matic 4036   |  |          |
| Check every 30000 miles/ 36 months, change every 60000 miles/ 72 months |  |          |

| HYDRAULIC BRAKE SYSTEM  |  |          |
|---|--|----------|
| USE   |  | CLIMATE  |
| Normal  |  | Moderate |
| PRODUCT RECOMMENDATION 1  |  |          |
| Drauliquid DOT 3  |  |          |
| Check every 15000 miles/ 18 months, change every 30000 miles/ 36 months |  |          |

## LEXUS (USA / CAN) RX XU30 RX 400H FWD (USA) (2006-2007)



| Capacity: 10,3 liter  |  |          |
|---|--|----------|
| USE   |  | CLIMATE  |
| Normal  |  | Moderate |
| PRODUCT RECOMMENDATION 1  |  |          |
| Coolant SP 14+  |  |          |
| Check every 15000 miles/ 18 months, change every 50000 miles/ 60 months |  |          |
| USE   |  | CLIMATE  |
| First change only   |  | Moderate |
| PRODUCT RECOMMENDATION 1  |  |          |
| Coolant SP 14+  |  |          |

Check every 15000 miles/ 18 months, change every 100000 miles/ 120 months

| COOLING SYSTEM INVERTER<br>Capacity: 3,4 liter |          |
|--|----------|
| USE  | CLIMATE  |
| Normal   | Moderate |
| PRODUCT RECOMMENDATION 1                       |          |
| Coolant SP 14+                                 |          |

Check every 15000 miles/ 18 months, change every 50000 miles/ 60 months

| USE   |  | CLIMATE  |
|---|--|----------|
| First change only   |  | Moderate |
| PRODUCT RECOMMENDATION 1  |  |          |
| Coolant SP 14+  |  |          |
| Check every 15000 miles/ 18 months, change every 100000 miles/ 120 months |  |          |

The data mentioned in this product information sheet is meant to enable the reader to orientate himself about the properties and possible applications of our products. Although this overview is composed with all possible care on the stated date, the compiler does not accept any liability for damages caused by incompleteness and/or inaccuracies in this information, especially when these are caused by obvious typing errors. The terms of delivery of the supplier apply to all product supplies. The reader is advised, especially for critical applications, to make the final product choice in consultation with the supplier. Due to continual product research and development, the information contained herein is subject to changes without notification.